

Recording Verification status of runtime values

On this page

- [Requirement/Instance table highlighted](#)
- [VerificationStatus stereotype](#)
- [Remember Failure Status option](#)

Requirement/Instance table highlighted

Magic Model Analyst supports recording verification status of runtime values. You can verify and record the status of constraints during runtime. If constraints are not met during the simulation, cells in the Requirement/Instance table will be highlighted in red on the **Variables** pane. You can do the normal recording verification status of runtime values by using the [resultLocation](#) tag in [SimulationConfig](#). The instances with recorded values in slots are created at the end of simulation.



Prerequisites

If you want constraint failures to be displayed in an Instance Table, the *Simulation Profile* must be used in your model.

The Requirement(s) table shows that the constraint in the Requirement is not met, thus the Requirement is colored in red as follows

#	Id	Name	Text	Satisfied By	Design Value	Verification St
1	1	Weight	The gross weight of the car shall be no more than 1700 kg	weight : kg = 1800.0 [Car]	1800.0 [Car::weight]	

Name	Value
Car {weight <= 1700.0}	Car@18e88d
weight : kg	1800.0000

The Requirement(s) table showing the constraint within a Requirement which is not met and colored in red.

If you right-click on the **Variables** pane and select **Export Value To > Instance**, the variables will be evaluated and colored in red if there are constraint failures in the instance table, as shown in the following figure

#	Name	Weight : Kg
1	car 1	2000.0
2	car 2	1800.0

Name	Value
Car {weight <= 1700.0}	Car@18e88d
weight : kg	1800.0000


Context Menu:

- Expand Recursively
- Export Value To
 - Instance...
 - New Instance...
- Save To Default Value(s)
- Show in Timeline
- Go To
- Select in Containment Tree Alt+B
- Create Sequence Diagram

The instance table showing the constraints after being exported to an Instance.

VerificationStatus stereotype


The status (pass/fail), related Requirements, and instances for constraints are recorded using the **VerificationStatus** stereotype that is applied on the **Value** specification of the properties that you are working on. You can also see the detail of the constraint failure in the tooltip when hovering the mouse over any highlighted red values in the Requirement/Instance table as shown in the following figure



Name	Value
Car {weight <= 1700.0, high <= 5.0}	Car@66714a
high : meter	3.0000
weight : kg	1800.0000
highCheck : High Verification {high <= 5}	HighVerification@1daca93
weightCheck : Weight Verification {weig...	WeightVerification@598eco

The simulation console showing the variables which have met or not met the constraints.

In addition, failed verdict of **State Invariant** is highlighted with red values and the tooltip. However, you must create a Dependency relation between the testcase and value property as shown in the following figure.




#	Name	system : System	tc1 : VerdictKind
1	test at 2018.01.10 12.15	test.system8 : System	fail
2	test at 2018.01.10 12.16	test.system9 : System	fail
3	test at 2018.01.10 12.20	test.system : System	fail
4	test at 2018.10.05 10.42	test.system10 : System	fail
5	test at 2018.10.05 10.43	test.system11 : System	fail
6	test at 2018.10.05 10.52	test.system13 : System	fail

Model view: bdd [Package] SimpleTestWithClock [Model]

```
graph TD
    Test["«block»  
Test  
values  
tc1 : VerdictKind = inconclusive"]
    System["«block»  
System"]
    Testcase["«testcase»  
testcase1"]
    Test -- system --> System
    Test -- d1 --> Testcase
```

Failed State Invariant with highlighted red values and the tooltip.

If the **VerificationStatus** state on the **Value** specification fails, the active validation will be marked for notification with the **fail** status tag as shown in the following figure




The Specification dialog showing verification status with the fail status tag.

The **VerificationStatus** stereotype, as shown in the figure above, has the tags as follows

Tag	Description
constraint	The name of the failure constraint.
margin	The Requirement margin value calculated from value properties and the Requirement boundary (a satisfy Relation).
requirement	The name of the failure Requirement.
status	The result of the verification, either pass or fail.
timestamp	The timestamp of the first failure recorded.

Remember Failure Status option

During the evaluation of particular configurations and scenarios, some Requirements/constraints can fail, and those values are marked in red. However, they may pass later and are marked in green again, but the failure is not recorded by default. To solve this problem, Simulation Toolkit provides the **Remember Failure Status** option in «SimulationConfig» to remember any failure status until the termination and record it as fail, even though it passes at the end. If the **Remember Failure Status** option is set true, and there are constraint failures during the simulation, the first fail status will be recorded in the status of «VerificationStatus» of new/recorded instance, and the time of the first failure will also be recorded in the **timestamp** tag as shown in the figure below.



Setting the Remember Failure Status tag of a SimulationConfig to record the fail status and timestamp if available.

Related pages

- [Requirement Table](#)
- [Variables pane](#)