


# Constraint Parameter

A **Constraint Parameter** is the formal term for a variable that appears in a constraint expression. It is displayed as a small square attached to the boundary on the inside of a [Constraint Property](#).



## Related diagrams

- [SysML Internal Block Diagram](#)
- [SysML Parametric Diagram](#)

## Related pages

- [Creating Constraint Parameters automatically](#)