## **Interface Block**

An Interface block is a special kind of block for typing proxy ports. It has no behaviors or internal parts. Normally, it contains a set of flow properties that can be shown in the **flow properties** compartment.

«interfaceBlock»
FS_ICE
<i>flow properties</i> out engineData : ICEData in mixture : Real in throttlePosition : Real

Visibility representation sysML, properties and operations of the Block are public. Visibility representation literals, like +, #, ~, -, are not displayed in the Containment tree or in the element symbol on a diagram.

## **Related pages**

SysML Block Definition Diagram