Integration with pure::variants

To start working with pure::variants projects, you need to integrate pure::variants application with your modeling tool first.

Prerequisites

- The Pure Variants Integration and Variability Core plugins are installed in your modeling tool.
- The *PureVariantsProfile.mdzip* profile is used in your model.

To integrate pure::variants with a modeling tool

---

1. Open a pure::variants project in your modeling tool.
2. In the main menu, select **Tools** > **Integrations**.
3. In the **Integrations** dialog, select the pure::variants integration and click the **Integrate/Remove Integration** button.
4. In the **pure::variants Integration** dialog, click ... and navigate to the pure::variants installation directory.
5. Click the **Integrate** button.



6. When you are prompted to restart the application click **OK** and close the **Integrations** dialog.
7. Restart your modeling tool.

Related pages

- Integration with Big Lever Software Gears
- Creating variants using transformations

Other resources

- Product Line Engineering with Cameo Systems Modeler and pure::variants. A record of the webinar.